



MOVINCOOL: TROUBLESHOOT

If you are seeing an error code on the screen that says **DRAIN TANK FULL**, please follow the following steps to clear the code and continue use.



1. Open the bottom door on the front of the unit.
2. Remove tank and empty the water.
3. Replace the tank, close the door.
4. Press the "clear" button to reset and return to the home screen.

Watch a video: www.axisair.com/help