



EMERGENCY PREPAREDNESS: It is the responsibility of the property owner and/or site manager to locate and familiarize themselves with the water shut-off valve prior to activation of this unit. In the event of a leak or emergency, immediate access to the shut-off valve is essential to prevent water damage.

CRITICAL HANDLING NOTICE: All water lines, drainage lines, and fittings connected to this unit must remain untouched and unmoved after installation. Any attempt to adjust, reposition, or manipulate these lines may compromise the integrity of the system and lead to leaks or equipment failure. Axis Portable Air is not liable for any damage resulting from post-installation movement, tampering, or unauthorized modifications to plumbing connections or components.

OCEANAIRE: TROUBLESHOOT

If you are seeing a CON code, the unit has had the **water turned off to it momentarily, not enough water flow, water is too hot, or a combination of those.** To clear this code and reset the unit:v



1. Turn the unit off by hitting the power button.
2. Make sure the water source is turned on with the cold water fully open.
3. Push in until you feel a 'click' on the small red button located near the bottom of the unit where the hoses connect.
4. Turn the power back on.

Watch a video: www.axisair.com/help